



Maintenance and Repair Instructions - -

- Always extend the lift arm and completely lower the deck to the ground before performing maintenance or repairs.
- Disarm the energy sources below before performing maintenance on the system.

1.) **Disable Gravity & pent-up loaded weight or (kinetic energy):**

- Lower the Deck to the ground, detach deck.
- Leave lift arm in a neutral, non-powered position, whereby no weight could crush anything or anyone.
- Clamp or prop-up any weight that cannot be relieved before working on unit.

2.) **Disable Electrical:**

- Disconnect battery power.

3.) **Disable Hydraulic:**

- **Relieve** pressure before disconnecting hydraulic lines.
- **After maintenance, Tighten** all connections before applying **hydraulic** pressure.
- **Protect** hands and body from high-pressure fluid leaks.
- **Wear** protective eyewear and gloves if accessing the hydraulic systems.
- Search for leaks with a piece of paper. **Warning:** Escaping fluid under pressure can penetrate the skin causing serious injury including amputation.



Maintenance:

- Grease all pivot pins every 60-90 days
- Grease wheel axles every 60-90 days
- Lubricate “slide in” rolling wheel bars every 60-90 days
- Maintain a “good” electrical ground connection
- Keep the oil reservoir topped up (use Dexron Automatic Transmission Oil)
- Spray all electrical connections with anti corrosion spray or apply lithium grease.

The SuperDeck must be treated with the same care and respect as any power tool.

Carelessness and unsafe operating, or failing to observe the safety instructions may result in serious injury or possible death to the operator or bystander.

Safety is for everyone.