



## **Safety Instructions for the SuperDeck**

- Only trained, qualified personnel over age 18 may be allowed to operate the SuperDeck/ChoreMaster.
- Operate only on **FIRM, LEVEL** surface.
- Never allow anyone to ride or climb on the deck while it is in motion.
- Always make sure there is sufficient clearance around the truck before lowering the deck, behind, as well as in front as a heavy off-load could push or skid the truck forward on slippery surfaces.
  - Never stand behind the deck while it is being raised or lowered.
  - Never stand in front of the truck while deck is being lowered.
- Always be sure the cargo is safely secured before raising or lowering the deck.
- Never exceed the load rating of the vehicle where the SuperDeck/ChoreMaster is installed, and
- Never exceed the 2000 lb. load rating of the SuperDeck/ChoreMaster unit.
- Never “drive” or move the truck unless the deck is in a “full up” position.
- Always stand well clear of the truck and moving deck.
- Never operate the SuperDeck while under the influence of drugs or alcohol.
- Disconnect and safely store or lock your “Pendant Hand Control” where it will not be accessible to any unauthorized person while the truck is unattended.